

HOW TO USE THE AUDIO LOOP HEARING RECEIVER



The audio loop system is designed to work **ONLY** with hearing aids equipped with a telecoil. So the loop receiver and headphones are only needed by those who do not have hearing aids equipped with a telecoil or who have a hearing problem, but do not use hearing aids. If you are unsure if your hearing aids or implant is equipped with a telecoil, you should check with your hearing professional.

To use the loop receiver, connect the headphones, sit within the designated loop reception area, and adjust the loudness control to a comfortable level.

Please return the receiver to sound controller at the end of program. PLEASE! Do not leave it un-attended on your seat.

This instruction card has been downloaded as a free community service from Christian Services for the Blind and Hearing-impaired. <http://csfbhi.adventistchurch.com/resources-page/> Ph +61 2 9847 2223

HOW TO USE THE AUDIO LOOP HEARING RECEIVER



The audio loop system is designed to work **ONLY** with hearing aids equipped with a telecoil. So the loop receiver and headphones are only needed by those who do not have hearing aids equipped with a telecoil or who have a hearing problem, but do not use hearing aids. If you are unsure if your hearing aids or implant is equipped with a telecoil, you should check with your hearing professional.

To use the loop receiver, connect the headphones, sit within the designated loop reception area, and adjust the loudness control to a comfortable level.

Please return the receiver to sound controller at the end of program. PLEASE! Do not leave it un-attended on your seat.

This instruction card has been downloaded as a free community service from Christian Services for the Blind and Hearing-impaired. <http://csfbhi.adventistchurch.com/resources-page/> Ph +61 2 9847 2223

HOW TO USE THE AUDIO LOOP HEARING RECEIVER



The audio loop system is designed to work **only** with hearing aids equipped with a telecoil. So the loop receiver and headphones are only needed by those who do not have hearing aids equipped with a telecoil or who have a hearing problem, but do not use hearing aids. If you are unsure if your hearing aids or implant is equipped with a telecoil, you should check with your hearing professional.

To use the loop receiver, connect the headphones, sit within the designated loop reception area, and adjust the loudness control to a comfortable level.

Please return the receiver to sound controller at the end of program. PLEASE! Do not leave it un-attended on your seat.

This instruction card has been downloaded as a free community service from Christian Services for the Blind and Hearing-impaired. <http://csfbhi.adventistchurch.com/resources-page/> Ph +61 2 9847 2223