

HOW TO USE THE “LISTEN” INFRA-RED RECEIVER



- (1) *(For hearing aids with a telecoil)* Put neck loop around neck.
- (2) Switch infra-red receiver ON.
- (3) Switch hearing aids to 'telecoil' mode.
- (4) Adjust loudness levels on infra-red receiver and hearing aids for comfort.
- (5) *(For users without hearing aids)* Connect optional headphones to receiver and adjust loudness level for comfort.
- (6) Do not cover front of receiver during use because audio quality may be affected.

Please return the receiver and attachments to sound controller at the end of program. PLEASE! Do not leave equipment un-attended on your seat.

This instruction card has been downloaded as a free community service from Christian Services for the Blind and Hearing-impaired. <http://csfbhi.adventistchurch.com/resources-page/> Ph +61 2 9847 2223

HOW TO USE THE “LISTEN” INFRA-RED RECEIVER



- (1) *(For hearing aids with a telecoil)* Put neck loop around neck.
- (2) Switch infra-red receiver ON.
- (3) Switch hearing aids to 'telecoil' mode.
- (4) Adjust loudness levels on infra-red receiver and hearing aids for comfort.
- (5) *(For users without hearing aids)* Connect optional headphones to receiver and adjust loudness level for comfort.
- (6) Do not cover front of receiver during use because audio quality may be affected.

Please return the receiver and attachments to sound controller at the end of program. PLEASE! Do not leave equipment un-attended on your seat.

This instruction card has been downloaded as a free community service from Christian Services for the Blind and Hearing-impaired. <http://csfbhi.adventistchurch.com/resources-page/> Ph +61 2 9847 2223

HOW TO USE THE “LISTEN” INFRA-RED RECEIVER



- (1) *(For hearing aids with a telecoil)* Put neck loop around neck.
- (2) Switch infra-red receiver ON.
- (3) Switch hearing aids to 'telecoil' mode.
- (4) Adjust loudness levels on infra-red receiver and hearing aids for comfort.
- (5) *(For users without hearing aids)* Connect optional headphones to receiver and adjust loudness level for comfort.
- (6) Do not cover front of receiver during use because audio quality may be affected.

Please return the receiver and attachments to sound controller at the end of program. PLEASE! Do not leave equipment un-attended on your seat.

This instruction card has been downloaded as a free community service from Christian Services for the Blind and Hearing-impaired. <http://csfbhi.adventistchurch.com/resources-page/> Ph +61 2 9847 2223